

### TRANSPONDER - LED USER GUIDE

Firmware: 903ff2e

---

Pulsating orange



Charging

---

Constant green



Charging complete

---

Blinking yellow



Standby

(Searching for satellite signals)

---

Blinking green



Online

---

Blinking red



Error

(Press button to restart)

---